


## Checking the Page Counters

You can see the machine's Page Counters for copies, printed pages, reports and lists or a summary total.

- 1 Press **Menu**, **6**, **3**.




- 2 Press **▲** or **▼** to see Total, List, Copy or Print.
- 3 Press **Stop/Exit**.

## Checking the remaining life of parts

You can see the machine's parts life on the LCD.

- 1 Press **Menu**, **6**, **7**.



- 2 Press **▲** or **▼** to choose 1. Drum, 2. Fuser, 3. Laser, 4. PF Kit MP, 5. PF Kit 1 or 6. PF Kit 2<sup>1</sup>. Press **OK**.
- 3 Press **Stop/Exit**.

<sup>1</sup> If the optional lower tray is installed on DCP-8150DN or DCP-8155DN.

### Note

The life check will be accurate only if you have reset the part counter when you installed a new part. It will not be accurate if that part's life counter was reset during the life of the used part.

The remaining life of the toner cartridge is listed on the User Settings report. (See *User Settings List* >> page 5.)

## Replacing periodic maintenance parts

The periodic maintenance parts will need to be replaced regularly to maintain the print quality. The parts listed below will have to be replaced after printing approximately 50,000 pages<sup>1</sup> for PF Kit MP and 100,000 pages<sup>1</sup> for PF Kit 1, PF Kit 2<sup>2</sup>, Fuser and Laser. Please call Brother Customer Service when the following messages appear on the LCD.

LCD message	Description
Replace Parts Fuser Unit	Replace the fuser unit.
Replace Parts Laser Unit	Replace the laser unit.
Replace Parts PF Kit 1	Replace the paper feeding kit for the paper tray.
Replace Parts PF Kit 2 <sup>2</sup>	Replace the paper feeding kit for the lower tray (option).
Replace Parts PF Kit MP	Replace the paper feeding kit for the multi-purpose tray.

<sup>1</sup> Letter or A4 size single-sided pages.

<sup>2</sup> If the optional lower tray is installed on DCP-8150DN or DCP-8155DN.